



WEATHERBEATER™ FLOOR LINERS CARE AND USE INSTRUCTIONS

PT #1937

Thank you for selecting a WeatherBeater® Floor Liner from Husky Liners. Your new 2nd seat liner is custom molded to fit your vehicle. The liner is made to take the place of your factory floor mats. **For correct fit, it is necessary to remove the factory floor mats before installing your new floor liners.** However, do not remove the factory-installed carpeting.

Your liner is made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge. If using a cleaner, 409® or Glass Plus® work well. Use of Armor All®, Son-of-a-Gun® or similar items is discouraged as these products make the liner slick.

INSTALLATION INSTRUCTIONS FOR YOUR FORD F-150 SUPERCREW 2nd SEAT FLOOR LINER



TO EASE INSTALLATION OF YOUR 2ND SEAT LINER, FIRST MOVE THE FRONT ROW SEATS TO THEIR MOST FORWARD POSITIONS. ONCE THE LINER IS INSTALLED, YOU CAN REPOSITION THE FRONT ROW SEATS AS DESIRED.

NOTE THAT ON SUPERCREW MODELS WITH 40/20/40 SPLIT BENCH FRONT ROW SEATS, A SMALL PORTION OF THE LINER WILL TUCK UNDER THE EDGES OF THE CUPHOLDER – SEE THE IMAGE ON BACK OF THIS PAGE.



WEATHERBEATER™ FLOOR LINERS

PT #1937

LINER TUCKS UNDER CORNERS OF CUP HOLDER ON
FRONT ROW 40/20/40 SPLIT BENCH SEAT MODELS.

