



X-ACT CONTOUR

FLOOR LINERS

CARE AND USE INSTRUCTIONS – PN:53141

Thank you for selecting Xact Contour™ Front Floor Liners from Husky Liners Inc. Your new front floor liners are custom molded to fit your specific vehicle's floor board. The liners are made to take the place of your factory floor mats. **For correct fit, it is necessary to remove the factory floor mats before installing your new floor liners.** However, do not remove the factory-installed carpeting.

Your liners are made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liners is with a damp cloth or sponge and soap and water. Windex®, 409® and ArmorAll® type cleaners work as well.



LEFT OR DRIVER



RIGHT OR PASSENGER

TO INSTALL DRIVER'S SIDE LINER SIMPLY POSITION LINER OVER THE EXISTING RETAINER AND PRESS DOWN TO SEAT LINER OVER THE RETAINER. PLEASE REVIEW BACK OF PAGE FOR FURTHER DETAILS.



53141

DEPENDING ON THE FACTORY OPTIONS INSTALLED ON YOUR VEHICLE, YOUR PASSENGER'S SIDE LINER MAY REQUIRE TRIMMING. TO DETERMINE IF TRIMMING IS NEEDED, INSTALL THE PASSENGER SIDE LINER AND OBSERVE THE PORTION OF THE LINER THAT MATCHES UP TO THE UPPER RIGHT HAND KICK PANEL. IF THE LINER APPEARS TOO WIDE AND DOES NOT LIE FLAT, YOU WILL NEED TO TRIM YOUR LINER. IF THE LINER CONTOURS THE AREA CORRECTLY, NO TRIMMING IS NEEDED.

TO TRIM, LOCATE THE STEP MOLDED INTO YOUR LINER ALONG THE RIGHT HAND EDGE (SEE IMAGE BELOW). USE THE STEP AS A TRIMMING GUIDE AND REMOVE THE EXCESS MATERIAL. A UTILITY KNIFE OR HEAVY SHEARS WORK WELL FOR TRIMMING.

