



X-ACT CONTOUR

FLOOR LINERS

CARE AND USE INSTRUCTIONS – PN:53421

Thank you for selecting a X-act Contour Floor Liner from Husky Liners Inc. Your new floor liners are custom molded to fit your Ford F250 or F350 Super Cab truck. The liners are made to take the place of your factory floor mats. **For correct fit, it is necessary to remove the factory floor mats before installing your new floor liners.** However, do not remove the factory-installed carpeting.

Your liners are made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liners is with a damp cloth or sponge. If using a cleaner, 409® or Glass Plus® work well. Use of Armor All®, Son-of-a-Gun® or similar items is discouraged as these products make the liners slick.

INSTALLATION INSTRUCTIONS FOR YOUR FORD F-SERIES SUPER DUTY SUPER CAB TRUCK FLOOR LINER

FRONT OF
VEHICLE



TO EASE INSTALLATION OF YOUR REAR SEAT SUPER CAB FLOOR LINER, FIRST MOVE THE FRONT SEATS TO THEIR MOST FORWARD POSITIONS. WITH THIS DONE, INSERT THE LINER IN YOUR VEHICLE THEN REPOSITION THE FRONT SEATS AS DESIRED.

IF YOUR TRUCK HAS THE FACTORY JACK TOOL POUCH LOCATED UNDER THE REAR PASSENGER SEAT, YOUR LINER CAN EASILY BE TRIMMED TO ALLOW THE TOOLS TO MOUNT ON TOP OF THE INSTALLED LINER. TO DO THIS, SIMPLY TRIM AWAY THE RECESSED MATERIAL FROM THE TOP OF THE RAISED LOCATING BOSS MOLDED INTO THE LINER (SEE AREA "1" ABOVE AND ATTACHED PHOTOS ON THE FOLLOWING PAGE). NEXT, REMOVE THE JACK TOOL POUCH ASSEMBLY BY REMOVING THE WING NUT RETAINING STUD. WITH

53421

THIS DONE, INSTALL YOUR LINER AND REPLACE THE TOOL POUCH ASSEMBLY, SECURING IT IN PLACE WITH THE ORIGINAL BRACKETS AND WING NUT STUD.



SHOWN TRIMMED FOR THE INSTALLATION OF THE JACK TOOL POUCH ON TOP OF THE LINER. TO TRIM, SIMPLY REMOVE THE MATERIAL FROM THE TOP OF THE RAISED BOSS AS SHOWN. A UTILITY KNIFE WORKS WELL FOR TRIMMING.