



## X-ACT CONTOUR® FLOOR LINERS

PT #5583

### CARE AND USE INSTRUCTIONS

---

Thank you for selecting an X-act Contour™ Floor Liners from Husky Liners Inc. Your new liners are custom molded to fit your specific vehicle's floor board. The liners are made to take the place of your factory floor mat. ***For correct fit, it is necessary to remove the factory floor mats before installing your new floor liners. However, do not remove the factory-installed carpeting.***

Your liners are made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liners is with a damp cloth or sponge and soap and water. Windex®, 409® and ArmorAll® type cleaners work as well.



TO INSTALL YOUR 2<sup>ND</sup> SEAT LINER, FIRST MOVE YOUR FRONT ROW SEATS COMPLETELY FORWARD. THEN, INSTALL YOUR NEW LINER, POSITIONING IT IN THE VEHICLE AS SHOWN ABOVE. IF YOUR VEHICLE HAS A FRONT ROW CONSOLE BETWEEN THE BUCKET SEATING, YOU WILL NEED TO TRIM YOUR LINER AS SHOWN ABOVE. TO TRIM, USE A UTILITY KNIFE OR HEAVY SHEARS AND, USING THE MOLDED IN TRIM GUIDE, REMOVE THE SECTION OF THE CENTER HUMP COVERAGE THAT MATCHES UP TO THE FRONT ROW CONSOLE. LASTLY, REPOSITION YOUR SECOND ROW SEATS AS DESIRED.