

**3500 Sierra Dually Rear****REAR MUD GUARD INSTALLATION INSTRUCTIONS**

*Please read instructions thoroughly before installation.*

**Tools Required**

- T20 Torx

**Package Contents**

- Driver & Passenger Side Rear Mud Guard
- Spring Clip X 2
- Instruction Sheet

**NOTE:** Turn the front wheels all the way to the left or right for mud guard installation. However, it may be necessary to remove the wheels depending on the tools being used for installation.

**Determine which mudguard you have by locating the part number molded in the mounting flange (5767 DS and 5767 PS).**

1. Clean and degrease the mud guard location area on the fender before installation.
2. Remove existing fasteners from locations A, B, and C.
3. Attach mud guard to front fender with factory fasteners at locations A, B, and C, check fit and make sure mud guard is parallel to ground before tightening.
4. Install Spring Clip as shown. Clips install over mud guard and fender, securing mud guard in place.

