



Standard Install Instructions

12" x 23" Truck Hardware Gatorback "Full Style" Mud Flaps

IMPORTANT: *The manufacturer is not responsible for negligent use of vehicle with mud flaps installed, including over-tightening of screws and bolts causing damage to vehicle or mud flaps.*

TOOLS REQUIRED:

- 1/2" or 3/8" drill
- 3/8" Socket Driver
- 1/4" Drill Bit

KIT CONTAINS:

- A. 8 - Tek Screws, 1/4" x 1"
- B. 8 - Flat Washers
- C. 1 - Set of Mud Flaps, drivers side & passengers side

INSTALLATION:

For ease of installation, it is suggested that the wheel be removed.

1. Before you install your Gatorback Mud Flaps, see the parts list for all necessary parts. Start on the driver's side.
2. Square the flap with the tire while putting pressure against the wheel well with the required height. The outside edge of the flap should be 1/2" past the wheel well.
3. Now fasten the flap with four washers and four tek screws. (Tip: Start with the top screw, this will allow you adjust the flap as needed)
4. Repeat procedure for the passenger side. Recheck all fasteners for tightness.

