



Installation Instructions

04-06 Toyota Tundra Double Cab

T0480CC, T0489CC, T0498CC-6

Bolt Kit:# T04

- 6) 8mm x 1" bolts
- 6) 8mm nuts
- 12) 5/16 Flat washers
- 12) 8mm Lock washers

Tools Needed:

- 13mm wrench
1. Remove the bars from their box and locate the bolt kit
 2. Find the driver and passenger sides; the short end goes towards the front
 3. Remove the 8mm bolt between the pinch-weld and the underside floor pan
 4. Line up the studs with the top hole in the bracket
 5. Finger-tighten the nuts and washers to the studs
 6. Put the bolts in the lower hole about half way in until all the bolts are in place the same way
 7. Tighten the front bolt, rear bolt, and then proceed with the rest until they are all tight
 8. Repeat the process on the other side
 9. You are now DONE!

Questions: Call (281) 880-NFAB

Fichter Designs licensed to N-FAB Inc. are protected U.S. Patent Law and International Copyright Law. N-FAB products configuration protected by International Trade Dress Law. U.S. Patent #6588783, other patents, and continuance pending. All Design & Patent infringements will be prosecuted to the full extent of the law.