


If you have any comments or concerns,
please feel free to contact our
customer service department at:
Toll-free: 1-800-835-0438
OR
Email: info@gofia.com

SEAT COVERS
BY




INSTALLATION INSTRUCTIONS
FOR
Part # TR42-1

FEATURING
SUPER-GRIP®
THE SLIP RESISTANT FASTENING SYSTEM

Thank you for purchasing one of our fine quality products. Your seat cover is engineered from high quality materials and designed with precision to give you a long-lasting, well-adjusted fit.

The **Super Grip Buckles** are self-locking. For proper usage, see diagram.



CUSHION COVER:

1. position seat cover over seat to align opening for release latch (looped straps on 1999 F Series Super Duty)
2. pull seat cover tightly side to side so that the front and back flaps tuck under seat
3. unlatch seat cushion and place in up position
4. pass the front straps under the seat and buckle to back flap

NOTE: SEATS WITH REMOVABLE HEADRESTS:

- remove headrest (if unable to remove consult your auto dealership)
- slit hole(s) into the stretch fabric to accommodate the headrest post(s)

THE STRETCH FABRIC WILL NOT RUN.

BACKREST COVER:

1. unlatch backrest and slip cover over
2. pull backrest cover down firmly making sure seat belt openings are aligned with seat belt holder
3. unlatch seat belts from holders
4. tuck flap under backrest and attach to velcro at back
5. adjust all straps/buckles and velcro to equalize the tension for a uniform fit

WARNING: SEATS WITH INTEGRATED SEAT AIRBAGS MUST BE COVERED ONLY WITH SEATCOVERS DESIGNED WITH OPENINGS THAT WILL NOT INTERFERE WITH THE DEPLOYMENT OF THE AIRBAG. NEVER INSTALL SEAT COVERS WITHOUT THESE OPENINGS AS THIS MAY INTERFERE WITH THE PROPER DEPLOYMENT OF THE AIR BAGS AND COULD RESULT IN SERIOUS INJURY.



Fia Inc. Winnipeg, Canada R3L 0N3 Telephone: (204) 475-0515 Toll-Free: 1-800-835-0438
Fax: (204) 284-8246 E-Mail: info@gofia.com Website: www.gofia.ca