



WEATHERBEATER™ FLOOR LINERS

PT #2579

CARE AND USE INSTRUCTIONS

Thank you for selecting a WeatherBeater™ Cargo Liner from Husky Liners. Your new trunk liner is custom molded to fit your Ford Explorer and is manufactured using an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge. If using a cleaner, 409® or Glass Plus® work well. Do not use Armor All®, Son-of-a-Gun® or similar items as these products make the liner slick.

CARGO LINER INSTALLATION INSTRUCTIONS FOR YOUR TOYOTA HIGHLANDER

1. Upon removal from the box your liner will not completely unroll and lay flat. This is normal and only temporary. Just place the liner on the floor or in the cargo area of your vehicle with a weight in each corner (a book works well). After about 15 minutes, your liner will remain flat. In colder temperatures this “relaxing” may take longer; moving the liner to a heated area will speed the process. At this time, check the back of the liner to make sure all 8 Velcro squares are installed over the 2-inch circular pieces adhered to the liner. If any are missing, please check for them in the packaging.



2. As boxed, the liner is not “split” to allow the 3rd row seat backs to fold independently. If you wish to have this functionality, the seat back portion can be split down the middle as shown in the photo. There is a trim groove molded in the center of the liner to guide trimming.



3. To access the LATCH attachment points on the back of the larger 3rd row seat back, you will need to trim your liner. Use the recessed trough around the inside bottom of the opening. A utility knife works well for trimming.





WEATHERBEATER™ FLOOR LINERS

PT #2579

4. Install the liner as shown – install with the 3rd row folded flat. You may need to press the liner down to fully seat the Velcro pads in place. The liner has allowances for the pull “belts” on the back of the 3rd row seats to pass through the liner



5. The first time the rear seat backs are moved to the upright position, move the seats slowly taking care to insure the accordion section of the liner folds outward as shown. This may need to be assisted from the backside.



6. The liner at this point is fully installed and is ready to use. If the liner needs to be removed, grab the rectangular Velcro patches and hold them firmly in place as you pull the liner from the seat. This Velcro piece is intended to stay attached to the seat back and cargo floor to reduce wear from the liner being installed and reinstalled for cleaning. Note that the liner includes slots that the seat pull handle will pass through.

