



# GATORGEAR NERF BOARD


By *Innovative Creations International*

Carton 1 of 2 - Front & Rear Tube Assembly  
#760383 & 760387

Carton 2 of 2 - Bracket and Fastener Kit  
#760548

## 03-09, DODGE QUAD CAB, DUALY #760028

Qty	Part #	Description	Qty	Part #	Description
1	Assembled	Front Driver Side Bracket	2	018045	5/8" Flat Pltd Washer
1	Assembled	Front Passenger Side Bracket	6	762236	3/8" x 1" T-bolt
1	Assembled	Middle Driver Side Bracket	8	025015	3/8" Hex Nut
1	Assembled	Middle Passenger Side Bracket	20	018046	3/8" Flat Pltd Washer
1	Assembled	Middle Rear Driver Side Bracket	20	024006	3/8" Lock Washer
1	Assembled	Middle Rear Passenger Side Bracket	12	014012	3/8" x 1-1/2" Cap Screw
1	Assembled	Rear Driver Side Bracket	2	014025	1/2" x 1-1/2" Carriage Bolt
1	Assembled	Rear Passenger Side Bracket	2	014026	3/8" x 1-1/4" Carriage Bolt
2	014021	5/8" x 2" Cap Screw	2	018048	1/2" Flat Pltd Washer
2	024003	5/8" Lock Washer	2	024007	1/2" Lock Washer
2	760552	2" Flat Side Washer	2	025016	1/2" Hex Nut
			19.5'	080407	Bulb Seal



- |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p><b>Step 1</b> Remove front cab mount bolt and install front bracket with the factory bolt.</p> <p><b>Step 2</b> Remove second cab mount bolt and install second bracket loosely with the factory bolt. Repeat process for the third and rear brackets.</p> <p><b>Step 3</b> Lay assembled board on the middle and rear brackets and use jackstand to steady if available, install board to front bracket using 5/8" x 2" cap screw with 5/8" flat washer. Level to body line and tighten.</p> | <p><b>Step 4</b> Install front, second and third bracket support strap using 3/8" x 1-1/2" T-bolt and 3/8" x 1-1/2" cap screw with 3/8" flat washer, 3/8" lock washer and 3/8" hex nut.</p> <p><b>Step 5</b> Install rear bracket to rear spring shackle factory holes using 3/8" x 1-1/2" cap screws with 3/8" flat washer, 3/8" lock washer and 3/8" hex nut.</p> <p><b>Step 6</b> Remove any plastic wrap around bracket saddles and install 3/8" x 1-1/2" cap screws with 3/8" flat washer and 3/8" lock washer into the bottom of tube. Repeat process for opposite side.</p> |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

Strip board of any plastic covering, check all nuts and bolts for tightness and repeat procedure for the opposite side.