

# 56124

## NISSAN JUKE

### WIRING LOCATION GUIDE GUÍA DE UBICACIÓN DEL CABLEADO IDE D'EMPLACEMENT DES FILS



#### MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

#### ¡DEBE LEERSE PRIMERO!

Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.

#### À LIRE D'ABORD!

Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement filéée.

10/22/2010



### English

1. Open the lift gate (A). Remove the spare tire cover, foam storage tray, spare tire and the rear scuff panel (B,C). On the driver and passenger sides pull out on the rear trim panel to locate the vehicle's taillight wiring harnesses (D). The harnesses will have connectors that are similar to those on the T-Connector harness.

2. On the driver side separate the connectors taking care not to damage the locking tabs (E). Insert the T-Connector end with the yellow wire between the separated connectors. Make sure the connectors are fully inserted with locking tabs in place.

3. Route the T-Connector end with the green wire across to the passenger side under the removed rear scuff panel. Repeat Step 2 on the passenger side using T-Connector end with the green wire.

4. Adhere the black converter box to the frame of the vehicle using the double-sided tape provided. Secure any loose parts of the T-Connector with the cable ties provided.

**WARNING!**  
Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.

5. Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure white ground wire using ring terminal and screw provided.

6. Reinstall all items removed during install.

7. Route the 4-flat wire out from under the rear trim panel and to the center of the vehicle. When in use, extend 4-flat from hatch. When not in use, roll up and store in an out of the way location in the rear cargo area.

