


IMPORTANT:


Manufacturer is not responsible for negligent use of vehicle with mud flaps installed, including over-tightening of screws and bolts causing damage to vehicle or mud flaps.




TOOLS REQUIRED



5/16 & 3/8" Open End Wrench & Socket Wrench



10mm open end or Socket Wrench



Electric or Chargeable 1/2" or 3/8" Drill




3/8" Socket Driver




1/4" Drill Bit

FLAPS

(1) Flap Assembly, Front, DS




(1) Flap Assembly, Front, PS




PARTS BAG # 766126

a) (8) Washer, Flat 0.203" x 1", SS Part #018081




b) (2) Washer, Lock #10, Helicoil, SS Part #024001



c) (2) Hex Nut #10, SS Part #025003




d) (2) Mach. Screw #10-24 x 1", SS Part #012022




INSTALLATION *(For ease of installation it is suggested that the wheel be removed)*

1. Before you install your Gatorback Mud Flap, see the diagram and parts list for all necessary parts.
2. Remove two (2) factory screws #4 & #5. Using the two (2) factory screws and included washers, reinstall on holes #1 & #2. Loosely secure at this point.
3. Square the flap with the tire, while putting pressure against the wheel well, then tighten the two (2) factory screws #4 & #5.
4. Hold flap tight against wheel well and drill 1/4" hole (1), from the center of the slotted hole #3 through the factory plastic liner. Secure the flap with one (1) machine screw #012022, two (2) flat washers #018031, one (1) lock washer #024001 and one (1) hex nut #025003.
5. Repeat procedure for passenger side.



REMOVE THE FACTORY SCREWS AND REINSTALL THROUGH HOLES #1 AND #2



Please check out our YouTube channel to see an install video for this application.

